## RECOMMENDED SEATING ARRANGEMENTS

## WARNING

According to the American Boat and Yacht Council's standard H-28.5.1 recommended seating arrangement must be specified.

RISK OF FALLING OVERBOARD

Recommended seating positions are marked with this symbol:

Add additional persons in the sequencs of numbers shown.

Do not exceed maximum persons or weight capacity.

See Capacity Label located on boat's transom for maximum capacities.

Avoid sharp turns at high speeds. Sharp turns at high speeds may result in passengers falling overboard.

Distribute weight of persons and gear evenly throughout boat.

When sitting on inflatable tubes use hand holds provided on tubes.

Generation Console RIBs (5 9 (7 (8) (7) (3) (6) 4 (6) (5)  $(\widehat{7})$ (8)(2)(6)(1)(2)(1)(2)(1)2)(1) Generation Generation 400 Generation 450 Generation 525 340 & 360 Genesis & Odyssey Super Tender RIBs Genesis & Odyssey ST Console RIBs 5 x 6 (5)  $(\overline{4})$ 5 **(4**)  $(\bar{3})$   $(\bar{1})$ (3)(1) $(\overline{4})$ 5 (3)(1)(1) $(\overline{2})$  $(\bar{2})$ (2) (2) (2)(4) $\langle \mathbf{4} \rangle$ (3)(2)(2)(4) (3)(1) $(\bar{3})$   $(\bar{1})$ 3)(1) Genesis 270 Genesis 310 Odyssey 365ST Genesis 340 & Odyssey 325ST Console Genesis 310 Genesis 340 & Odyssey 365ST Console Odyssey 325ST Console Console Original Line Odyssey Superlight & Odyssey Roll-ups 4)(1 $(\overline{4})$ ी  $\overline{(1)}$ (1)(1)(3) (2)(3) (2)(3) (2) 2 (2)WB8 **WB10** 275 RID 310 RID Odyssey 240 Odyssey 270 Odyssey 310

## RECOMMENDED SEATING ARRANGEMENTS

## WARNING

According to the American Boat and Yacht Council's standard H-28.5.1 recommended seating arrangement must be specified.

**RISK OF FALLING OVERBOARD** 

Recommended seating positions are marked with this symbol:

Add additional persons in the sequencs of numbers shown.

Do not exceed maximum persons or weight capacity.


See Capacity Label located on boat's transom for maximum capacities.

Avoid sharp turns at high speeds. Sharp turns at high speeds may result in passengers falling overboard.

Distribute weight of persons and gear evenly throughout boat.

When sitting on inflatable tubes use hand holds provided on tubes.

Generation LTE Console RIBs



Generation 10' LTE (3 Seats)

Generation 10' LTE Generation 11' LTE (4 Seats)

(3 Seats)


Generation 11' LTE Generation 12' LTE (4 Seats)

(4 Seats)


Generation 12' LTE

(5 Seats)


Venture Console RIBs




Venture 14' (4 seats)



Venture 14' (5 seats)



Venture 16' (4 seats)



Venture 16' (5 seats)